


文具 STATIONERY

Staedtler 活芯鉛筆
Staedtler Marsmicro Thinlead
Holder



0.3mm
A1104-8-775-03
0.5mm
A1104-8-775-05
0.7mm
A1104-8-775-07
0.9mm
A1104-8-775-09

Staedtler 幼鉛芯
Staedtler Micrograph Thinlead



0.3mm, 12pcs
A1104-8A-250-03
0.5mm, 12pcs
A1104-8A-250-05
0.7mm, 12pcs
A1104-8A-250-07
0.9mm, 12pcs
A1104-8A-250-09

Staedtler 顏色鉛芯
Staedtler Micrograph Colour Lead



0.5mm, 12pcs
A1104-8A-254-05

Faber-Castell 活芯鉛筆
Faber-Castell Auto Mechanical
Pencil



0.5mm
A1104-8-133910

Staedtler 活芯鉛筆
Staedtler Technical Lead Holder



2mm
A1104-8-780C

Staedtler 繪圖鉛芯
Staedtler Lumograph Lead



2mm, 12pcs
A1104-8A-200
Blue, 2mm, 12pcs
A1104-8A-204-3

中華牌鉛筆
Chung Wah Pencil #6151



12pcs
A1104-1-6151

LYRA 粗三角鉛筆
LYRA Triangle Thick Pencil



A1104-1-9760

Staedtler 三角特粗鉛筆
Staedtler Triplus Learn 's Pencil



12pcs
A1104-1-119T

Staedtler 鉛筆
Staedtler Noris Pencil



12pcs
A1104-1-120

Staedtler 黃桿鉛筆
Staedtler Yellow Pencil



12pcs
A1104-1-134

UNI 撕紙蠟筆
UNI Chinagraph Pencil



C8111-4-7600

UNI 原子筆
UNI Ball Point Pen



Red / Blue / Black
A1103-SN101

雙珠啫喱筆
UNI Sign Pen



Gold / Silver
C4073-UM100

速記防水啫喱筆
UNI Roller Ball Gel Pen



Gold / Silver
C4073-UM153

UNI 水筆
UNI Ball Eye Pen



C4073-150

UNI 水筆
UNI Roller Ball Pen




C4073-155

Pentel 顏色簽名筆
Pentel Sign Pen

Red / Blue / Black
C4073-S520

Comix 資料簿, 4孔
Comix Clear Holder, 4 Holes



A3, 20 pages
A1301-NF20-A3

Comix 資料簿
Comix Clear Holder



A4, 20 pages
A1301-A448
A4, 40 pages
A1301-A450

不織布筆袋
Non Woven Pencil Bag



12.5 "W x 12 "H
A1104A-B1003

Comix 資料簿, 30孔
Comix Clear Holder, 30 Holes



A4, 20 pages
A1301-NF406-A4

Comix 資料簿內頁, 11孔
Comix Reill for Comix Holder, 11 Holes

A3, 10shts
A1302-EH309

網紋拉鍊袋
Plastic Bag with Zipper



A4 size
A1373-MP-A4

Comix 資料簿內頁, 30孔
Comix Refill for Comix Holder, 30 Holes

A4, 20shts
A1302-EH304

Data-Bank 資料簿
Data-Bank Clear Holder



A4, 20 pages
A1301-3020
A4, 40 pages
A1301-3044

網紋拉鍊袋
Plastic Bag with Zipper

透明資料夾
Clear Holder



A4
A1301-GE310
F.S
A1301-E355
A3
A1301-E310

Data-Bank 資料簿內頁
Data-Bank Refill for 3020

A4, 20shts
A1302-3020

Data-Bank 資料簿內頁
Data-Bank Refill for 3044

A4, 20shts
A1302-3044

文具 STATIONERY

Pilot 塗改帶
Pilot Correction Tape



5mm
A1021-ECTE-SP5

Pentel 塗改帶
Pentel Correction Tape



5mm
A1021-ZT45

3M 報示貼板
3M Post-it Board



18 "x 23 "
A1314-558

Pilot 塗改帶替芯
Pilot Correction Tape Refill



5mm
A1021-ECTRF-SP5

Pentel 塗改帶替芯
Pentel Correction Tape Refill



5mm
A1021-ZTR5

3M 報示貼
3M Post-it Note Stripe



14mm x 75mm
A1314-550R
38.1mm X 50.8mm
A1314-653-1
76.2mm x 76.2mm
A1314-654-1
76.2mm x 127mm
A1314-655-1
50.8mm x 76.2mm
A1314-656-1

Tipp-Ex 套裝塗改液
Tipp-Ex Correction Fluid Set



20ml
A1021-4203

Pentel 塗改液筆
Pentel Correction Pen



18ml
A1021-P

Pentel 塗改液筆
Pentel Correction Pen-Fine Point



12ml
A1021-PF

3M 4色報示貼標籤
3M Post-it Note Stripe



4 colours
A1314-683-4

Max 雙孔打孔機
Max Punch, Double Holes



A1521-DP-F2B

Max 雙孔打孔機
Max Paper Punch, Double Holes



A1521-DP-F2D

証件套
Plastic Name Plate with String




90mm x 110mm
A1353-1

名片膠牌
Plastic Name Plate



57mm x 91mm
A1353

黑色長尾夾
Pouble Foldback Clip



3/4"
A1402-112
1"
A1402-111
1 1/4"
A1402-110
1 5/8"
A1402-109
2"
A1402-108

白鋼夾
Silver Paper Clip



1 1/2"
A1402-UA38
2"
A1402-UA50
2 1/2"
A1402-UA63
3"
A1402-UA75

活頁圈
EPL Bookrings



1", 100pcs
A1304-100
1 1/2", 100pcs
A1304-140

Globe X 字夾
Globe X Shape Paper clips



6pcs
A1421-139

萬字夾
Paper Clip



No. 1, 100pcs
A1421-1
No. 3, 100pcs
A1421-3

萬字夾
EPL Paper Clips



50mm, 100pcs
A1421-E350

文具 STATIONERY

Derwent 電芯鉛筆刨
Derwent Battery Operated Helical
Pencil Sharpener



A1511-2300174

Derwent 電動鉛筆刨
Derwent Battery Pencil Sharpener



A1511-2301934

Derwent 粉彩鉛筆刨
Derwent Pastel Pencil Sharpener



A1512-0700234

雙孔鉛筆刨
Metal Pencil Sharpener,
Double Hole



A1511-E92085

單孔鉛筆刨
Metal Pencil Sharpener,
Single Hole



A1511-E91688

UNI 電動鉛筆刨
UNI Electrical Pencil Sharpener



A1511-UNI

UNI 手動鉛筆刨
UNI Pencil Sharpener



A1511-KH-18

Carl 手動鉛筆刨
Carl Pencil Sharpener-ANGEL-5



A1511-A-5

Staedtler 鉛筆刨
Staedtler Noris Plastic Sharpener



A1512-511-004

Staedtler 活芯鉛筆刨
Staedtler Mars Lead Pointer



A1511-502

Staedtler 活芯鉛筆刨
Staedtler Lead Sharpener



A1511-513-85

Staedtler 鉛筆刨
Staedtler Plastic Sharpener



A1512-511-001

Staedtler 雙孔鉛筆刨
Staedtler Noris Club Pencil Sharpener



A1511-512-128

Crayola 3孔鉛筆刨
Crayola 3-in-1 Trio Pencil
Sharpener



AC64-6824

Derwent 電動擦膠筆套裝
Derwent Battery Eraser & Replacement



A1651-2301931

Crayola 蠟筆鉛筆刨
Crayola Crayon Tip Sharpener



AC64-3450

Derwent 電動擦膠筆替蕊
Derwent Replacement Erasers



30pcs
A1651A-2300023

Staedtler 擦膠
Staedtler Mars Plastic Eraser



A1651-526-50

Staedtler 擦膠
Staedtler Rasoplast Eraser



A1651-526-B30

KUM 鉛筆刨
KUM Plastic Pencil Sharpener



A1512-KUM

Staedtler 擦膠筆
Staedtler Pencil Eraser with Brush



A1651-526-61

Staedtler 擦膠
Staedtler DUO PLAST Ink / Pencil
Eraser




A1651-526-BT30

Pilot 擦膠
Pilot Foam Eraser



A1651-ER-F6



12pcs
CC49-283

Crayola 特粗顏色粉筆
Crayola Side walk Chalks



15 colours, 15pcs
CC51-8015

Crayola 可擦螢光筆
Crayola Erasable Highlighter



Chisel Tip
CC76-6804

Fine Tip
CC76-6809

Crayola 顏色無塵粉筆
Crayola Anti-Dust Color Chalks




5 colours, 12pcs
CC49-284

Crayola 特粗顏色粉筆
Crayola Side walk Chalks



24 colours, 52pcs
CC51-8052

Staedtler 螢光筆
Staedtler Fluorescent Marker



C4076-364

Crayola 黃色無塵粉筆
Crayola Anti-dust Yellow Chalks



12pcs
CC50-1401

Crayola 蛋形粉筆
Crayola Egg & Chick Shapes Chalks



6 colours, 6pcs
CC51-4106